

**TUH2(XV95) SERIES REPAIR PARTS REV. 1/21/2019**

| <b>PART NUMBER</b> | <b>DESCRIPTION</b> | <b>TUH2B060</b> | <b>TUH2B080</b> | <b>TUH2C100</b> | <b>TUH2D120</b> |
|--------------------|--------------------|-----------------|-----------------|-----------------|-----------------|
| BLW00879           | INDUCER BLOWER     | X               | X               | X               | X               |
| BNR01077           | BURNER             | X               | X               | X               | X               |
| CNT06585           | CONTROL BOARD      | X               | X               | X               | X               |
| IGN00152           | IGNITER            | X               | X               | X               | X               |
| MOD02175           | V/S MOTOR MODULE   |                 |                 |                 | X               |
| MOD02176           | V/S MOTOR MODULE   |                 |                 | X               |                 |
| MOD02177           | V/S MOTOR MODULE   | X               | X               |                 |                 |
| MOT15032           | MOTOR 1/2 HP       | X               |                 |                 |                 |
| MOT15033           | MOTOR 3/4 HP       |                 |                 | X               | X               |
| MOT15307           | MOTOR 1/2 HP       |                 | X               |                 |                 |
| SEN01114           | FLAME SENSOR       | X               | X               | X               | X               |
| SEP00243           | SEPARATOR TRAP     | X               | X               | X               | X               |
| SWT01635           | THERMAL LIMIT      | X               | X               | X               |                 |
| SWT01651           | THERMAL LIMIT      |                 |                 |                 | X               |
| SWT01714           | DOOR SPST SWITCH   | X               | X               | X               | X               |
| SWT02685           | INDUCER LIMIT      | X               | X               | X               | X               |
| SWT02979           | PRESSURE SWITCH    |                 | X               | X               | X               |
| SWT03114           | PRESSURE SWITCH    | X               |                 |                 |                 |
| SWT02124           | FLAME ROLL OUT     | X               | X               | X               | X               |
| TRR01729           | TRANSFORMER        | X               | X               | X               | X               |
| VAL09031           | 2 STAGE TX-VALVE   | X               | X               | X               | X               |